

MODEL	DBS100A13R8	DBS150A12	DBS150A15	DBS150A24
MAX OUTPUT WATTAGE[W]	100.7	150	150	151
DC OUTPUT	13.8V 7.3A	12V 12.5A	15V 10A	24V 6.3A

SPECIFICATIONS

	MODEL		DBS100A13R8	DBS150A12	DBS150A15	DBS150A24		
	VOLTAGE[V]		DC45 - 160	DC66 - 160		·		
INPUT	CURRENT[A]	*1	1.10typ	1.57typ	1.59typ	1.58typ		
EFFICIENCY[%]		*1	83typ	87typ	86typ	87typ		
	VOLTAGE[V] CURRENT[A] LINE REGULATION[mV]		13.8	12	15	24		
			7.3	12.5	10	6.3		
			60max	40max	60max	95max		
	LOAD REGULATIO	N[mV]	150max	100max	150max	190max		
		0 to +85°C *2	120max	120max	120max	120max		
	RIPPLE[mVp-p]	-20 - 0 ℃ *2	160max	160max	160max	160max		
ουτρυτ	RIPPLE NOISE[mVp-p]	0 to +85°C *2	150max	150max	150max	150max		
001901	RIPPLE NOISE[mvp-p]	-20 - 0 ℃ *2	180max	180max	180max	180max		
		0 to +65℃	180max	120max	180max	280max		
	TEMPERATURE REGULATION[mV]	-20 to +85℃	310max	200max	310max	480max		
	DRIFT[mV] *3		60max	40max	60max	90max		
	START-UP TIME[ms]		200max (DCIN 110V, Io=100%)					
	OUTPUT VOLTAGE ADJUSTME	NT RANGE	Fixed (TRM pin open), 60 - 110% adjustable by external VR or external voltage					
	OUTPUT VOLTAGE SET	TING[V]	13.25 - 14.35	11.60 - 12.60	14.40 - 15.60	23.04 - 24.96		
	OVERCURRENT PROT	ECTION	Works over 105% of rating	g and recovers automatica	lly			
PROTECTION CIRCUIT AND	OVERVOLTAGE PROTE	ECTION	15.87 - 19.32V	13.80 - 16.80V	17.25 - 21.00V	27.60 - 33.60V		
OTHERS	REMOTE SENSING	•	Provided					
	REMOTE ON/OFF		Provided (On both side of	input and output)				
	INPUT-OUTPUT		AC3,000V 1minute, Cutof	f current = 10mA, DC500V	/ 50MΩ min (20±15℃)			
ISOLATION	INPUT-FG		AC2,000V 1minute, Cutof	f current = 10mA, DC500V	/ 50MΩ min (20±15℃)			
IOULATION	OUTPUT-FG		AC500V 1minute, Cutoff current = 100mA, DC500V 50M Ω min (20±15°C)					
	OUTPUT-RC2,RC3		AC100V 1minute, Cutoff current = 100mA, DC100V 10M Ω min (20±15°C)					
	OPERATING TEMP.,HUMID.AND	ALTITUDE		1 /	densing) (Refer to DERATING CU	JRVE), 3,000m (10,000feet) m		
ENVIRONMENT	STORAGE TEMP.,HUMID.AND	ALTITUDE	-40 to +85°C, 20 - 95%RH (Non condensing), 9,000m (30,000feet) max					
	VIBRATION		10 - 55Hz, 49.0m/s ² (5G), 3minutes period, 60minutes each along X, Y and Z axis					
	IMPACT		196.1m/s ² (20G), 11ms once each along X, Y and Z axis					
SAFETY	AGENCY APPROV	-	UL60950, C-UL, EN60950					
OTHERS	CASE SIZE/WEIGH		61 x 12.7 x 116.8mm (W x	, 0				
	COOLING METHO	D	Conduction cooling (e.g. h	neat radiation from the alu	minum base plate to the at	tached heat sink)		

*1 At rated input(DC110V) and rated load.
 *2 Ripple and ripple noise is measured by using measuring board with the recommended capacitor Co & the film capacitor 0.1 µ F. Measured by 20MHz oscilloscope or Ripple-Noise meter (Equivalent to KEISOKU-GIKEN:RM101).

*3 Drift is the change in DC output for an eight hour period after a half-hour warm-up at 25°C, with the input voltage held constant at the rated input/output.



MODEL	DBS200B03	DBS200B05	DBS200B07	DBS200B12
MAX OUTPUT WATTAGE[W]	165	200	210	240
DC OUTPUT	3.3V 50A	5V 40A	7.5V 28A	12V 20A

SPECIFICATIONS

	MODEL		DBS200B03	DBS200B05	DBS200B07	DBS200B12		
	VOLTAGE[V]		DC200 - 400					
INPUT	CURRENT[A]	*1	0.75typ	0.86typ	0.87typ	0.99typ		
	EFFICIENCY[%]	*1	79typ	83typ	86typ	87typ		
	VOLTAGE[V] CURRENT[A] LINE REGULATION[mV]		3.3	5	7.5	12		
			50	40	28	20		
			16max	20max	30max	40max		
	LOAD REGULATIO	DN[mV]	30max	40max	60max	100max		
		0 to +85°C *2	80max	80max	100max	120max		
	RIPPLE[mVp-p]	-20 - 0℃ *2	140max	140max	150max	160max		
OUTPUT		0 to +85°C *2	100max	100max	140max	150max		
001901	RIPPLE NOISE[mVp-p]	-20 - 0℃ *2	150max	150max	160max	180max		
	TEMPERATURE REGULATION[mV]	0 to +65℃	35max	50max	75max	120max		
		-20 to +85℃	60max	85max	130max	200max		
	DRIFT[mV] *3		16max	20max	30max	40max		
	START-UP TIME[ms]		200max (DCIN 280V, Io=100%)					
	OUTPUT VOLTAGE ADJUSTMENT RANGE		Fixed (TRM pin open), 60 - 110% adjustable by external VR or external voltage					
	OUTPUT VOLTAGE SE	TTING[V]	3.25 - 3.45	4.90 - 5.20	7.25 - 7.85	11.60 - 12.60		
		ECTION	Works over 105% of ratin	g and recovers automatica	lly			
PROTECTION CIRCUIT AND	OVERVOLTAGE PROT	ECTION	4.00 - 5.50V	5.75 - 7.00V	8.60 - 10.50V	13.80 - 16.80V		
OTHERS	REMOTE SENSING	3	Provided					
	REMOTE ON/OFF		Provided (On both side of	input and output)				
	INPUT-OUTPUT		AC3,000V 1minute, Cutof	f current = 10mA, DC500V	′ 50MΩ min (20±15℃)			
ISOLATION	INPUT-FG		AC2,000V 1minute, Cutof	f current = 10mA, DC500V	′ 50MΩ min (20±15℃)			
ISOLATION	OUTPUT-FG		AC500V 1minute, Cutoff of	current = 100mA, DC500V	50MΩ min (20±15℃)			
	OUTPUT-RC2,RC3		AC100V 1minute, Cutoff current = 100mA, DC100V 10M Ω min (20±15°C)					
	OPERATING TEMP.,HUMID.AND) ALTITUDE	-20 to +85℃ (On aluminum bas	e plate), 20 - 95%RH (Non conc	lensing) (Refer to DERATING CL	JRVE), 3,000m (10,000feet) ma		
ENVIRONMENT	STORAGE TEMP.,HUMID.AND	ALTITUDE	-40 to +85°C, 20 - 95%RH (Non condensing), 9,000m (30,000feet) max					
	VIBRATION		10 - 55Hz, 49.0m/s ² (5G), 3minutes period, 60minutes each along X, Y and Z axis					
IMPACT		196.1m/s ² (20G), 11ms once each along X, Y and Z axis						
SAFETY	AGENCY APPROV	ALS	UL1950, C-UL, EN60950,	VDE0160 Complies with I	DEN-AN and IEC60950			
OTHERS	CASE SIZE/WEIGH	IT	61 × 12.7 × 116.8mm (W ×	(HXD) / 150g max				
UTTERS	COOLING METHO	D	Conduction cooling (e.g. heat radiation from the aluminum base plate to the attached heat sink)					

*1 At rated input(DC280V) and rated load.
*2 Ripple and ripple noise is measured by using measuring board with the recommended capacitor Co & the film capacitor 0.1 µ F. Measured by 20MHz oscilloscope or Ripple-Noise meter (Equivalent to KEISOKU-GIKEN:RM101).
*3 Drift is the change in DC output for an eight hour period after a half-hour warm-up at 25°C, with the input voltage held constant at the rated input/output.



MODEL	DBS400B03	DBS400B05	DBS400B07	DBS400B12	DBS400B15	DBS400B18	DBS400B24	DBS400B28
MAX OUTPUT WATTAGE[W]	264	400	405	408	405	396	408	406
DC OUTPUT	3.3V 80A	5V 80A	7.5V 54A	12V 34A	15V 27A	18V 22A	24V 17A	28V 14.5A

SPECIFICATIONS

N	IODEL		DBS400B03	DBS400B05	DBS400B07	DBS400B12	DBS400B15	DBS400B18	DBS400B24	DBS400B2
v	OLTAGE[V]		DC200 - 400)						
INPUT C	CURRENT[A] *1		1.19typ	1.72typ	1.68typ	1.67typ	1.66typ	1.61typ	1.67typ	1.63typ
E	EFFICIENCY[%] *1		79typ	83typ	86typ	87typ	87typ	89typ	87typ	88typ
v	VOLTAGE[V] CURRENT[A] LINE REGULATION[mV] LOAD REGULATION[mV]		3.3	5	7.5	12	15	18	24	28
С			80	80	54	34	27	22	17	14.5
L			16max	20max	30max	40max	60max	60max	95max	95max
L			30max	40max	60max	100max	150max	150max	190max	190max
	RIPPLE[mVp-p]	0 to +85°C *2	80max	80max	100max	120max	120max	120max	120max	120max
ĸ	KIPPLE[IIIvp-p]	-20 - 0℃ *2	140max	140max	150max	160max	160max	160max	160max	160max
	IPPLE NOISE[mVp-p]	0 to +85℃ *2	100max	100max	140max	150max	150max	150max	150max	150max
		-20 - 0 ℃ *2	150max	150max	160max	180max	180max	180max	180max	180max
те	EMPERATURE REGULATION[mV]	0 to +65℃	35max	50max	75max	120max	180max	180max	280max	280max
		-20 to +85℃	60max	85max	130max	200max	310max	310max	480max	480max
D	DRIFT[mV] *3		16max	20max	30max	40max	60max	60max	90max	90max
S	START-UP TIME[m	ns]	200max (DCIN 280V, Io=100%)							
0	UTPUT VOLTAGE ADJUSTME	NT RANGE	Fixed (TRM	pin open), 60	- 110% adjus	stable by exte	rnal VR or ex	ternal voltage	e	
0	UTPUT VOLTAGE SET	rting[v]	3.25 - 3.45	4.90 - 5.20	7.25 - 7.85	11.60 - 12.60	14.40 - 15.60	17.28 - 18.72	23.04 - 24.96	26.88 - 29.
	VERCURRENT PROT	ECTION	Works over	105% of rating	g and recover	rs automatica	ly			
	VERVOLTAGE PROT			5.75 - 7.00V	8.60 - 10.50V	13.80 - 16.80V	17.25 - 21.00V	20.70 - 25.20V	27.60 - 33.60V	32.20 - 39.2
OTHERS	REMOTE SENSING	6	Provided							
R	REMOTE ON/OFF		Provided (On both side of input and output)							
	NPUT-OUTPUT					mA, DC500V		,		
ISOLATION-	NPUT-FG					mA, DC500V	(,		
C	OUTPUT-FG					nA, DC500V	,	,		
-	DUTPUT-RC2,RC3					nA, DC100V	,			
-	PERATING TEMP.,HUMID.AND	-							IRVE), 3,000m (*	10,000feet) m
FNVIRONMENT	TORAGE TEMP.,HUMID.AND	ALTITUDE		-40 to +85°C, 20 - 95%RH (Non condensing), 9,000m (30,000feet) max						
V	/IBRATION			0 - 55Hz, 49.0m/s² (5G), 3minutes period, 60minutes each along X, Y and Z axis						
	MPACT					Ig X, Y and Z				
-	GENCY APPROV	-				omplies with D	EN-AN and I	EC60950		
OTHERS -	CASE SIZE/WEIGH				(HXD) / 180g	,				
C	COOLING METHO	D	Conduction of	cooling (e.g. h	neat radiation	from the alun	ninum base p	late to the att	ached heat si	ink)

*1 At rated input(DC280V) and rated load.
*2 Ripple and ripple noise is measured by using measuring board with the recommended capacitor Co & the film capacitor 0.1 µ F. Measured by 20MHz oscilloscope or Ripple-Noise meter (Equivalent to KEISOKU-GIKEN:RM101).
*3 Drift is the change in DC output for an eight hour period after a half-hour warm-up at 25°C, with the input voltage held constant at the rated input/output.

CO\$EL | B

Basic Characteristics Data

Model	Circuit method	Switching frequency	Raled mush rob/ration					Parallel availability		
woder	Circuit method	[kHz]	[A]	input fuse	input fuse protection	Material	Single sided	Double sided	Series operation	Parallel operation
DBS100A	Forward converter	370	1.10 * 1	-	-	Aluminum	Yes		Yes	Yes
DBS150A	Forward converter	370	1.59 <mark>*1</mark>	-	-	Aluminum	Yes		Yes	Yes
DBS200B	Forward converter	370	0.99 *1	-	-	Aluminum	Yes		Yes	Yes
DBS400B	Forward converter	370	1.72 <mark>*1</mark>	-	-	Aluminum	Yes		Yes	Yes

*1 The value of input current is at rated input and rated load.

Instruction Manual COSEL

1	Pin Connection	H-50
2	Connection for Standard Use	H-50
3	Wiring Input/Output Pin	H-50
		H-50 H-51
4	Function	H-52
	 4.1 Overcurrent protection 4.2 Overvoltage protection 4.3 Thermal detection/Thermal protection 4.4 Inverter operation monitor 4.5 Remote ON/OFF 4.6 Remote sensing 4.7 Adjustable voltage range 4.8 Isolation 	H-52 H-52 H-52 H-52 H-53 H-53
5	Series and Parallel Operation	H-54
	 5.1 Series operation 5.2 Parallel operation/Master-slave operation 	H-54
	5.3 N+1 redundant operation	
6		

DBS

1 Pin Connection

COSEL

Table 1.1 Pin connection and function

NO.	Pin Connection	Function	
1	+VIN	+DC input	
2	-VIN	-DC input	
3	RC1	Remote ON/OFF(Input side)	
4567	+VOUT	+DC output	
8911	-VOUT	-DC output	
12	СВ	Current balance	
13	VB	Voltage balance	
14	TMP	Thermal detection signal	
15	RC3	Remote ON/OFF(output side)	
16	RC2		
1	TRM	Adjustment of output voltage	
18	+S	+Remote sensing	
(19)	-S	-Remote sensing	
20	IOG	Inverter operation monitor	
2)	AUX	Auxiliary power supply	
	FG	Mounting hole(FG)	
		ine an ing noie (i e)	
NO.	Pin Connection	Reference	
NO.	-	Reference	
_	Pin Connection		
1	Pin Connection +VIN	Reference	
1 2	Pin Connection +VIN -VIN	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF"	
1 2 3	Pin Connection +VIN -VIN RC1	Reference 3.1 "Wiring input pin"	
1 2 3 4 5 6 7	Pin Connection +VIN -VIN RC1 +VOUT	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin"	
1 2 3 4 5 6 7 8 9 0 1	Pin Connection +VIN -VIN RC1 +VOUT -VOUT	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF"	
1 2 3 4 5 6 7 8 9 10 11 12	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin"	
1 2 3 4 5 6 7 8 9 10 11 12 13	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation" 4.3 "Thermal detection/Thermal protection"	
1 2 3 4 5 6 7 8 9 10 11 12 13 13	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB TMP	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation"	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 14	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB TMP RC3	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation" 4.3 "Thermal detection/Thermal protection"	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 15	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB TMP RC3 RC2	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation" 4.3 "Thermal detection/Thermal protection" 4.5 "Remote ON/OFF" 4.7 "Adjustable voltage range"	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB TMP RC3 RC2 TRM	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation" 4.3 "Thermal detection/Thermal protection" 4.5 "Remote ON/OFF"	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 15 16 17 18	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB TMP RC3 RC2 TRM +S	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation" 4.3 "Thermal detection/Thermal protection" 4.5 "Remote ON/OFF" 4.7 "Adjustable voltage range"	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 15 16 17 18 19	Pin Connection +VIN -VIN RC1 +VOUT -VOUT CB VB TMP RC3 RC2 TRM +S -S	Reference 3.1 "Wiring input pin" 4.5 "Remote ON/OFF" 3.2 "Wiring output pin" 5.2 "Parallel operation/Master-slave operation" 4.3 "Thermal detection/Thermal protection" 4.5 "Remote ON/OFF" 4.7 "Adjustable voltage range" 4.6 "Remote sensing"	



Fig.1.1 Pin connection(bottom view)

2 Connection for Standard Use

- In order to use the power supply, it is necessary to wire as shown in Fig.2.1.
 - Reference: 3 "Wiring Input/Output Pin"

6.5 "Derating"

■Short the following pins to turn on the power supply. -VIN⇔RC1, +VOUT↔+S, -VOUT↔-S

Reference: 4.5 "Remote ON/OFF"

4.6 "Remote sensing"

- The DBS Series handles only the DC input.
 - Avoid applying AC input directly.

It will damage the power supply.

Operate with the conduction cooling(e.g. heat radiation from the aluminum base plate to the attached heat sink).

(Reference: 6.5 "Derating")



Cin: External capacitor on the input side Co : External capacitor on the output side

CY : Primary decoupling capacitor

Fig.2.1 Connection for standard use

3 Wiring Input/Output Pin

3.1 Wiring input pin

(1) External fuse

- ■Fuse is not built-in on input side. In order to protect the unit, install the normal blow type fuse on input side.
- When the input voltage from a front end unit is supplied to multiple units, install the normal blow type fuse in each unit.

Model	DBS100A / 150A	DBS200B	DBS400B
Rated current	5A	ЗA	5A

Table 3.1 Recommended fuse(Normal-blow type)



- (2) Noise filte/Decoupling capacitor
- Install an external noise filter and a decoupling capacitor CY for low line-noise and for stable operation of the power supply.
- Install a correspondence filter, if a noise standard meeting is required or if the surge voltage may be applied to the unit.
- Install a primary decoupling capacitor CY, with more than 470pF, near the input pins(within 50mm from the pins).
- When the total capacitance of the primary decoupling capacitor is more than 8800pF, the nominal value in the specification may not be met by the Hi-Pot test between input and output.

In this case, it is that a capacitor should be installed between output and FG.

(3) External capacitor on the input side

Install an external capacitor Cin between +VIN and -VIN input pins for low line-noise and for stable operation of the power supply.

DBS100A / 150A:more than 47µF

DBS200B:more than 0.1µF

- DBS400B:more than 0.33µF
- ■When the line impedance is high or the input voltage rise quickly at start-up(less than 10µs), install a capacitor Cin between +VIN and -VIN input pins(within 50mm from pins).

DBS200B:more than 22^µF

DBS400B:more than 47^µF

(4) Input voltage rang/Input current range

- The specification of input ripple voltage is shown as below.
 - Ripple voltage DBS100A / 150A:less than 10Vp-p DBS200B / 400B:less than 20Vp-p
- Make sure that the voltage fluctuation, including the ripple voltage, will not exceed the input voltage range.
- Use a front end unit with enough power, considering the start-up current lp of this unit.



Fig.3.1 Input voltage ripple



Fig.3.2 Input current characteristics

(5) Operation with AC input

The DBS series handles only for the DC input.

A front end unit(AC/DC unit) is required when the DBS series is operated with AC input.

(6) Reverse input voltage protection

Avoid the reverse polarity input voltage. It will break the power supply.

It is possible to protect the unit from the reverse input voltage by installing an external diode.



Fig.3.3 Use with AC input



Fig.3.4 Reverse input voltage protection

3.2 Wiring output pin

- Install an external capacitor Co between +VOUT and -VOUT pins for stable operation of the power supply.
- Recommended capacitance of Co is shown in Table 3.2.
- Select the high frequency type capacitor. Output ripple and startup waveform may be influenced by ESR • ESL of the capacitor and the wiring impedance.
- Install a capacitor Co near the output pins(within 100mm from the pins).

Table									
Model Output voltage (V)	DBS100A DBS150A	DBS200B	DBS400B						
3.3	_	2200	6800						
5	—	2200	4700						
7.5	-	2200	4700						
12	1000	1000	2200						
13.8	1000	—	—						
15	1000	—	2200						
18	_	_	2200						
24	470	—	820						
28	—	—	820						

Table 3.2 Recommended capacitance Co [µF]

4 Function

4.1 Overcurrent protection

Overcurrent protection is built-in and comes into effect at over 105% of the rated current.

Overcurrent protection prevents the unit from short circuit and overcurrent condition. The unit automatically recovers when the fault condition is cleared.

When the output voltage drops at overcurrent, the average output current is reduced by intermittent operation of power supply.

4.2 Overvoltage protection

- ■The overvoltage protection circuit is built-in. The DC input should be shut down if overvoltage protection is in operation. The minimum interval of DC recycling for recovery is for 2 to 3 minutes(★).
 - ★ The recovery time varies depending on input voltage and input capacity.

Remarks:

Please note that devices inside the power supply might fail when voltage more than rated output voltage is applied to output terminal of the power supply. This could happen when the customer tests the overvoltage performance of the unit.

4.3 Thermal detection/Thermal protection

- Thermal detection(TMP) and protection circuit are built-in.
- When overheat is detected, thermal detection signal(TMP) turns "L" from "H".
- TMP circuit is designed as shown in Fig.4.1, and specification is shown as in Table 4.1.
- When overheating continues after detecting the TMP signal, the output will be shut down by the thermal protection circuit.
- When this function comes into effect, input voltage should be shut off, and eliminate all possible causes of overheat condition and lower the temperature of the unit to the normal level.

4.4 Inverter operation monitor

By using the inverter operation monitor(IOG), malfunction of the inverter can be monitored.

When inverter operation is in following mode ① or @, IOG signal turns "H" from "L" within 1 second.

IOG circuit is designed as shown in Fig.4.1 and specification is shown in Table 4.1.

1 Malfunction of inverter.

- ⁽²⁾ The output voltage drops by 60% or less of the rated voltage.
- ③ When output wattage is decreased radically to less than 10% of rated wattage.



Fig.4.1 TMP, IOG circuit

Table 4.1 Specification of TMP, IOG

No.	Item TMP		IOG	
1	Function	Normal operation "H"	Normal operation "L"	
'	FUNCTION	Overheat detection "L"	Malfunction of inverter "H"	
2	Base pin	-S		
3	Level voltage "L"	0.5Vmax at 5mA		
4	Level voltage "H"	e "H" 5V typ		
5	Maximum sink current	10mA max		
6	Maximum applicable voltage	ximum applicable voltage 35V max		

4.5 Remote ON/OFF

Remote ON/OFF circuit is built-in on both side of input(RC1) and output(RC2 · RC3).

Output can be controlled by either circuit.

- (1) Input side remote ON/OFF(RC1)
- The ground pin of input side remote ON/OFF circuit is "-VIN" pin.

Between RC1 and -VIN: Output voltage is ON at "Low" level or short circuit(0 - 1.0V).

Between RC1 and -VIN: Output voltage is OFF at "High" level or short circuit(3.5 - 7.0V).

When RC1 is "Low" level, fan out current is 0.3mA typ. When Vcc is applied, use $3.5 \le Vcc \le 7V$.

When remote ON/OFF function is not used, please short between RC1 and -VIN.

■When the DPA • DPF series(Power factor & harmonic corrector module) is used as a front end unit, connect between RC1 pin and PR pin on DPA(between RC1 pin and ENA pin on DPF) for the start-up timing of the DBS200B/400B control.

DBS





Fig.4.2 RC1 connection example

(2) Output side remote ON/OFF(RC2 · RC3)

No.	Item	RC2 · RC3			
1	Wiring method	Fig.4.3 (a)	Fig.4.3 (b)	Fig.4.3 (c)	
2	Function	Power ON "H" Power ON "H"		Power ON "L"	
3	Base pin	RC2	-S	-S and RC2	
4	Power ON	Open (0.1mA max)		Short (0.5V max)	
5	Power OFF	Short (3mA min)		Open (0.1mA max)	



Fig.4.3 RC2 · RC3 connection example

Make sure that sink current of output side remote ON/OFF circuit should be less than 12mA.

(3) Auxiliary power supply for remote ON/OFF(AUX)

■AUX is built in for operating the output side remote ON/OFF (RC2 • RC3).

If AUX is not used for RC2 · RC3, AUX can be used for IOG or TMP signal output by opto coupler.

■Short protection resistance(2.2kΩ) is built in.

Output voltage decreases as the output current increases. (AUX voltage at open circuit: 15V max)

4.6 Remote sensing

(1) When the remote sensing function is not in use

- When the remote sensing function is not in use, it is necessary to confirm that pins are shorted between +S & +VOUT and between -S & -VOUT.
- Wire between +S & +VOUT and between -S & -VOUT as short as possible.

Loop wiring should be avoided.

This power supply might become unstable by the noise coming from poor wiring.

(2) When the remote sensing function is in use

- Twisted-pair wire or shield wire should be used for sensing wire.
- Thick wire should be used for wiring between the power supply and a load.

Line drop should be less than 0.5V.

Voltage between +VOUT and -VOUT should remain within the output voltage adjustment range.

If the sensing patterns are short, heavy-current is drawn and the pattern may be damaged.

The pattern disconnection can be prevented by installing the protection parts as close as a load.







Fig.4.5 Connection when the remote sensing is in use

4.7 Adjustable voltage range

Output voltage is adjustable by the external potentiometer or by applied voltage externally.

The adjustable range is 60 - 110% of the rated output voltage.

When the output voltage adjustment is used, note that the overvoltage protection circuit operates when the output voltage sets too high.

DBS

(1) Adjusting method by external resistor

COSEL

- By connecting the external potentiometer(VR1) and resistors(R1, R2), output voltage becomes adjustable, as shown in Fig.4.6, recommended external parts are shown in Table 4.3.
- The wiring to the potentiometer should be as short as possible. The temperature coefficient becomes worse, depending on the type of a resistor and potentiometer. Following parts are recommended for the power supply.

Resistor ------- Metal film type, coefficient of less than ±100ppm/°C Potentiometer -- Cermet type, coefficient of less than ±300ppm/°C

When the output voltage adjustment is not used, open the TRM pin and VB pin respectively.



Fig.4.6 Output voltage control circuit

Table 4.3 Recommended value of external potentiometer & resistor

No.	Adjustable range [%]	Number of unit	External parts value [Ω]			
			VR1	R1	R2	
1	±5	Single	5k	75k	1k	
2		2 sets		36k		
3		3 sets		24k		
4	±10	Single	5k	36k	910	
5		2 sets		18k		
6		3 sets		12k		

(2) Adjusting method by applying external voltage

- By applying the voltage externally at TRM, output voltage become adjustable.
- Output voltage is calculated by the following equation.(Output voltage)
 - = (Applied voltage externally) × (Rated output voltage)

4.8 Isolation

■For a receiving inspection, such as Hi-Pot test, gradually increase(decrease) the voltage for a start(shut down). Avoid using Hi-Pot tester with the timer because it may generate voltage a few times higher than the applied voltage, at ON/OFF of a timer.

5 Series and Parallel Operation

5.1 Series operation

Series operation is available by connecting the outputs of two or more power supplies, as shown below. Output current in series connection should be lower than the lowest rated current in each unit.



Fig.5.1 Examples of series operation

5.2 Parallel operation/Master-slave operation

- Parallel operation is available by connecting the units as shown in Fig.5.2.
- As variance of output current drew from each power supply is maximum 10%, the total output current must not exceed the value determined by the following equation.

(Output current in parallel operation)

=(the rated current per unit) × (number of unit) × 0.9

When the number of units in parallel operation increases, input current increase at the same time. Adequate wiring design for input circuitry is required, such as circuit pattern, wiring and current capacity for equipment.

In parallel operation, the maximum operative number of units is 11.





Fig.5.2 Examples of parallel operation

- When output voltage adjustment is not in use. TRM wiring, R1, R2 and VR are not necessary.
- Thick wire should be used for wiring between the power supply and load, and line drop should be less than 0.3V.
- When the output-line impedance is high, the power supply is become unstable.

Use same length and thickness(width) wire(pattern) for the current balance improvement.

- Connect each input pin for the lowest possible impedance.
- When the number of the units in parallel operation increases, input current increases. Adequate wiring design for input circuitry such as circuit pattern, wiring and current for equipment is required.
- Connect the sensing line and the power line by one point after connecting each power supply's sensing pins(+S, -S). In multiple operation, sensing wires should be connected between each units for the muster connection to a load.
- Output current should be 10% or more of the total of the rated output current in parallel operation. If less than 10%, the IOG signal might become unstable, and output voltage slightly increasing (max5%).
- ■IOG signal might be unstable for one second when the units are turned on in parallel operation.

5.3 N+1 redundant operation

- It is possible to set N+1 redundant operation for improving reliability of power supply system.
- Purpose of redundant operation is to ensure stable operation in the event of single power supply failure.

Since extra power supply is reserved for the failure condition, so total power of redundant operation is equal to N-1.

Implementation • 6 **Mounting Method**

6.1 Mounting method

- The unit can be mounted in any direction. When two or more power supplies are used side by side, position them with proper intervals to allow enough air ventilation. Aluminum base plate temperature around each power supply should not exceed the temperature range shown in derating curve.
- Avoid placing the DC input line pattern lay out underneath the unit, it will increase the line conducted noise. Make sure to leave an ample distance between the line pattern lay out and the unit. Also avoid placing the DC output line pattern underneath the unit because it may increase the output noise. Lay out the pattern away from the unit.
- High-frequency noise radiates directly from the unit to the atmosphere. Therefore, design the shield pattern on the printed circuit board and connect its one to FG.

The shield pattern prevents noise radiation.



Fig.6.1 Shield pattern lay out(bottom view)

6.2 Stress onto the pins

When too much stress is applied to the pins of the power supply, the internal connection may be weakened.

As shown in Fig.6.2 avoid applying stress of more than 29.4N(3kgf) on the input pins/output pins(A part) and more than 9.8N(1kgf) to the signal pins(B part).

- The pins are soldered on PCB internally, therefore, do not pull or bend them with abnormal forces.
- ■Mounting hole diameter of PCB should be 3.5mm to reduce the stress onto the pins.
- Fix the unit on PCB(fixing fittings) by screws to reduce the stress onto the pins. Be sure to mount the unit first, then solder the unit.



6.3 Cleaning

COSEL

Clean the product with a brush. Prevent liquid from getting into the product.

Do not soak the product into liquid.

Do not stick solvent to a name plate or a resin case.

(If solvent sticks to a name plate or a resin case, it will cause to change the color of the case or to fade letters on name plate away.)

■After cleaning, dry them enough.

6.4 Soldering

■Flow soldering	: 260°C less than 15 seconds.		
■Soldering iron			
DC IN/DC OUT/RC1	: 450°C less than 5 seconds.		
Signal pins	: 350°C less than 3 seconds(less than 20w).		

6.5 Derating

Use with the conduction cooling(e.g. heat radiation by conduction from the aluminum base plate to the attached heat sink).

Fig.6.3 shows the derating curve based on the aluminum base plate temperature. In the hatched area, the specification of ripple and ripple noise is different from other areas.





Fig.6.3 Derating curve